

ME 553 Final Project

University of Michigan College of Engineering

Piezoresistive Sensor Design for Single Layer PDMS on Silicon Hybrid Micro Actuator with Multi Axis Out of Plane Motion Capabilities

Awais Kamboh Kamran Asim Bilal Mansoor

Motivation

- Use of PDMS in Mems.
- Out of plane actuation.
- □ Useful applications.
- □ High Bandwidth.





Precise control of hybrid Actuator.

Objectives:

- Design a sensor using the existing structure.
- Propose fabrication strategy.
- □ Parametric study of sensor.
- Design optimization.

Problem Setup

- □ Manufacturability.
- Structural compatibility of sensor to the platform.
- □ Capacitive / Resistive Sensor. Pros & Cons.
- Analysis of the sensor characteristics e.g. sensitivity, Bandwidth

Proposed Solution



Folded Flexure Beam

Cantilever Fabrication



Silicon Cantilever beam ready to be fabricated into Piezoresistive sensor.

KEY:



Processing: Piezoresistor B+



Cantilever beam is lightly doped by Piezoresistor, B+ Using oblique ion doping.

KEY:



Piezoresistive Doping



Processing: Conductor B++





Cantilever Fabrication



Sensor Design

- Folded Flexural Beams Modeling.
- Piezoresistive Expression.
- Wheatstone bridge Analysis.



Flexure Beam Modeling



Piezoresistive Expression



Electrical Circuit Analysis



Optimization

- Sensitivity Analysis
 - Actuator voltage
 - Displacement
- □ SCR optimization
 - Piezoresistors geometry
- Bandwidth Sensitivity Tradeoff
 - First natural frequency
 - Overall system bandwidth
- Effect of Noise and MDD
 - Johnson's noise





Results

- □ Tradeoff between Bandwidth and Sensitivity
 - We require sensitivity optimization
 - Inherent need due to high bandwidth actuation.

- Different Design Parameters effect Different Sensor Characteristics:
 - Cross-sectional Parameter (a,w): affects Sensitivity
 - Longitudinal Length Ratio (L): affects Bandwidth
 - SCR affects sensitivity

Future Work

- Transfer Function or State space Relationships for the System.
- Control Algorithm for Nanopositioning of the platform.
- Use of the platform in exciting Applications like the scanning probe microscope.

Questions?

